



SPRITE SYSTEM CONTROLS



Prime rinse pump

- 1 Press "Next" button until "13" appears on display.
- 2 Press "Enter" button.
- 3 Pump will run for 30 seconds.
- 4 Repeat until primed.

Check rack count

- 1 Press "Next" button.
- 2 Display will say "11."
- 3 Press "Enter" button.
- 4 Rack count will be displayed for 30 seconds.

De-Lime

- 1 Press "Next" button.
- 2 Display will say "11."
- 3 Press "Next" button until "14" appears on the display.
- 4 Press "Enter" button.
- 5 Display will say "600." This is 10 minutes worth of seconds.
- 6 The dispenser will count down 600 seconds the turn back on.
- 7 Press "Enter" to leave mode early.

PUR-O-ZONE

800-727-7876